DN SERIES

Network PTZ Pos.





Installation and Operations Manual

Model Number: DN1793T6ZMX Series

Network Hybrid PTZ Positioning Systems

Dante Security

DN1793T6ZM4 Hybrid PTZ Positioning Camera System

User Manual

Issue V1.1

Date 12-3-2025

Precautions

Precautions

Fully understand this document before using this device, and strictly observe rules in this document when using this device. If you install this device in public places, provide the tip "You have entered the area of electronic surveillance" in an eyecatching place. Failure to correctly use electrical products may cause fire and severe injuries. To prevent accidents, carefully read the following context:

Symbols

This document may contain the following symbols whose meanings are described accordingly.

Symbol	Description
A DANGER	It alerts you to fatal dangers which, if not avoided, may cause deaths or severe injuries.
MARNING	It alerts you to moderate dangers which, if not avoided, may cause minor or moderate injuries.
A CAUTION	It alerts you to risks. Neglect of these risks may cause device damage, data loss, device performance deterioration, or unpredictable results.
©—" TIP	It provides a tip that may help you resolve problems or save time.
NOTE	It provides additional information.



DANGER

To prevent electric shocks or other dangers, keep power plugs dry and clean.



WARNING

Strictly observe installation requirements when installing the device. The manufacturer shall not be held responsible for device damage caused by users' non-conformance to these requirements.

Strictly conform to local electrical safety standards and use power adapters that are marked with the LPS standard when installing and using this device. Otherwise, this device may be damaged.

Use accessories delivered with this device. The voltage must meet input voltage requirements for this device.

If this device is installed in places with unsteady voltage, ground this device to discharge high energy such as electrical surges in order to prevent the power supply from burning out.

When this device is in use, ensure that no water or any liquid flows into the device. If water or liquid unexpectedly flows into the device, immediately power off the device and disconnect all cables (such as power cables and network cables) from this device.

Do not expose the thermal imaging camera or unpacked product to extremely strong radiation sources, such as the sun, laser, or arc welding machine, regardless of whether the device is being electrified or not; do not put the camera close to high thermal objects such as the sunlight; otherwise, the precision of the camera may be affected and even the detector inside the camera may suffer a permanent damage.

If this device is installed in places where thunder and lightning frequently occur, ground the device nearby to discharge high energy such as thunder strikes in order to prevent device damage.



CAUTION

Unless otherwise specified, do not use the camera in a temperature lower than - $20 \, \text{°C} \, (-4 \, \text{°F})$ or higher than + $60 \, \text{°C} \, (+140 \, \text{°F})$. Too-high or too-low temperature may cause image display anomaly of the camera and the camera will be damaged if it is working under such a condition for a long time.

If the camera is installed outdoors, avoid direct sunlight at dawn and dusk on the camera lens and install a sunshield with frontal and rear positions adjusted according to the sunlight angle.

Avoid heavy loads, intensive shakes, and soaking to prevent damages during transportation and storage. The warranty does not cover any device damage that is caused during secondary packaging and transportation after the original packaging is taken apart.

Protect this device from fall-down and intensive strikes, keep the device away from magnetic field interference, and do not install the device in places with shaking surfaces or under shocks.

Clean the device with a soft dry cloth. For stubborn dirt, dip the cloth into slight neutral cleanser, gently wipe the dirt with the cloth, and then dry the device.

Since the camera lens is painted with a durable coating material, it adapts to outdoor environment. The lens must be cleaned regularly. If the image quality is reduced or excessive dirt is deposited on the lens, clean the lens in a timely manner. In sandy (in desert) or corrosive (on sea) environment, use the camera with caution; improper use may cause the coating to peel off.

Do not jam the ventilation opening. Follow the installation instructions provided in this document when installing the device.

Keep the device away from heat sources such as radiators, electric heaters, or other heat equipment.

Keep the device away from moist, dusty, extremely hot or cold places, or places with strong electric radiation.

If the device is installed outdoors, take insect- and moisture-proof measures to avoid circuit board corrosion that can affect monitoring.

Remove the power plug if the device is idle for a long time.

Before unpacking, check whether the fragile sticker is damaged. If the fragile sticker is damaged, contact customer services or sales personnel. The manufacturer shall not be held responsible for any artificial damage of the fragile sticker.

Special Notes

All complete products sold by the manufacturer are delivered along with nameplates, operation instructions, and accessories after strict inspection. The manufacturer shall not be held responsible for counterfeit products.

This manual may contain misprints, technology information that is not accurate enough, or product function and operation description that is slightly inconsistent with the actual product. The manufacturer will update this manual according to product function enhancement or changes and regularly update the software and hardware described in this manual. Update information will be added to new versions of this manual without prior notice.

This manual is only for reference and does not ensure that the information is totally consistent with the actual product. For consistency, see the actual product.

Contents

Precautions	i
1 Overview .	1
1.1 Principle of Thermal Imaging and Advantages	1
1.2 Product Introduction.	
1.2.1 Function	2
1.2.2 Product Features.	2
1.3 Description of PTZ cable	3
1.3.1 Aviation Power Supply and Network Cable of Twenty-six cores	3
1.3.2 Aviation Alarm Cable of Twenty-six Cores	4
2 Device Dimensions	7
3 Device Installation.	8
3.1 Installation Method	8
3.2 Device Installation.	8
3.2.1 Installation of Basic Requirements.	8
3.2.2 Basic Installation Tool.	8
3.2.3 Installation Space and Installation Strength	9
3.2.4 Definition of Installation Wiring Harness	9
4 Quick Configuration	11
4.1 Thermal Web	11
4.1.1 Login and Logout.	11
4.1.2 Main Page Layout .	12
4.1.3 Change the Password	13
4.1.4 Browse Video.	14
4.1.5 Install Plugins.	16
4.1.6 Set Local Network Parameters	16
4.2 Visible-light Web.	19
4.2.1 Login and Logout.	19
4.2.2 Main Page Layout	20
4.2.3 Change the Password	21
4.2.4 Browse Video.	22
4.2.5 Set Local Network Parameters	24

5 Thermal Settings	28
5.1 Temperature Parameters	
5.2 Temperature Area	32
5.3 Schedule Linkage	36
5.4 Bad Point Check.	38
5.5 Thermal Parameter Configuration	40
5.5.1 Access the Sensor Setting Interface	40
5.6 Sensor Setting Parameter.	41
5.6.1 Mode	41
5.6.2 Image Setting	41
5.6.3 Scene	43
5.6.4 Set Psecudocolor	43
5.6.5 FFC Control	44
5.6.6 Noise Reduction.	46
5.6.7 Enhance Image	47
6 Visible Sensor Configuration	49
6.1 Accessing the Sensor Interface	
6.2 Mode	49
6.3 Image Adjust	51
6.4 Scene	52
6.5 Exposure	53
6.6 WB	54
6.7 DayNight	55
6.8 Noise Reduction	58
6.9 Enhance Image	59
6.10 Zoom Focus	60
7 PTZ Function Application	62
7.1 PTZ Control function	
7.2 PTZ configuration .	
7.2.1 PTZ Setting	
7.2.2 Configure and Apply Preset	
7.2.3 Configure and Apply Tracks	64
7.2.4 Configure and Apply Scan	
7.2.5 Configure and Apply Tour.	
7.2.6 Configure and Applye Idle	
7.2.7 Configure North	
7.2.8 Configure Timer	
7.2.9 Configure Extension.	
A Troubleshooting	

1 Overview

1.1 Principle of Thermal Imaging and Advantages

Any object with temperature higher than the absolute zero (-273.15° F) will emit infrared (IR) ray, even though it does not emit light. The IR ray is also called thermal radiation. IR rays emitted by objects with different temperatures can be absorbed by the detector to reflect temperature change and thus generate an electric effect. The electric signal is amplified and processed to produce a thermal image that corresponds to the thermal distribution of the object surface. This is the process of thermal imaging.

Adapt to any environment

Traditional cameras rely on natural or environmental light to shoot images, but this IR thermal imaging camera relies on the IR energy radiated by an object itself to form an image, not requiring any light. The IR thermal imaging camera is applicable to any environment and not affected by light strength. It can detect and identify any camouflage and concealed object both in daytime or nighttime, implementing round-the-clock monitoring.

- Monitor the temperature field with object energy distributed
 - The IR thermal imaging camera can show the temperature field of an object, converting the invisible surface temperature distribution situation to a visible thermal image that reflects the surface temperature distribution situation of the object. By this monitoring, users can discover temperature anomaly in a timely manner and take precautionary measures to avoid any risk that may be caused by the anomaly, for example, a fire.
- Boast cloud penetration capability
 Visible light and near IR ray will be absorbed by the air, cloud and smoke, but they are transparent to IR ray of the 3~5 µm Medium Wavelength Infrared (MWIR)
 region and 8~14 µm Long Wavelength Infrared (LWIR) region. Traditional cameras cannot shoot clear images under cloudy environment, but the IR thermal imaging camera can penetrate the cloud and smoke to shoot clear images.

1.2 Product Introduction

Hybrid PTZ Pos. Camera System the whole machine shell and the base are all made of high strength aluminum alloy material with comprehensive function and high stability. Can adapt to a variety of bad environment, heavy load can reach

more than 50 kg and run smoothly. This series has $360\,^\circ$ continuous rotation, automatic scanning, automatic cruise and other functions, suitable for large areas of monitoring, can be widely used in airports, stations, urban roads, traffic survey and monitoring, forest fire prevention, the high and heavy equipment rotary control and other important area.

1.2.1 Function

To support a variety of scanning methods, such as cruise scan, pattern scanning, etc.

It supports the function of power off memory and automatically returns to the monitoring scene before power off.

Support network signal and analog signal double output, cloud platform control classification operation.

The double helix structure of worm gear and worm drive, the electronic image stabilization, and mechanical locking design, power self-locking function.

Horizontal continuous rotation 360 $^{\circ}$, vertically +45 $^{\circ}$ ~- 45 $^{\circ}$ rotating, horizontal velocity is 0.01 $^{\circ}$ ~60 $^{\circ}$ S, vertical speed of 0.01 $^{\circ}$ ~ 15 $^{\circ}$ S.

Support proportion variable times function, rotation speed adjusted automatically according to the lens change multiple times.

Support watch features preset point/figure/cruise can stay idle scan specified Automatic call after time (including the idle state entered after power).

1.2.2 Product Features

Outdoor intelligent variable speed PTZ, the fuselage selection of high strength aluminum alloy material, exterior design can resist strong winds, smooth operation, high precision.

Products using high-precision stepper motor and precision worm gear drive combination, power can be self-locking.

Support a variety of lens preset function, zoom adaptive function, the rotation speed can be automatically adjusted according to the lens zoom factor.

Powerful, with preset, cruise, line sweep, keep watch and other functions.

Visual pitch angle range, monitoring a wide range of horizontal speed up to 60° /s.

Equipment has its own automatic heating system, low temperature automatically start heating function, to ensure that products can be applied to cold areas.

Network transmission signal can reach 100 Mbps.

Device supports RS485 / RS422 communication interface, user may remotely upgrade the device program, easy to maintain.

Power failure memory function, accidental power after re-power, the memory of the last running state, can be restored to power before running state.

1.3 Description of PTZ cable

1.3.1 Aviation Power Supply and Network Cable of Twenty-six cores

Aviation power supply and network cable of twenty-six cores is shown as Figure 1-1 & Figure 1-2, and the description is shown in Table 1-1.



Figure 1-1 Aviation power supply and network cable of twenty-six cores

Figure 1-2 Definition of twenty-six cores




Table 1-1 Description of twenty-six cores

SN	Name	Description
1	DC36V -	Black (Thick)
2	DC36V +	Red (Thick)
3	DC36V -	Black (Thick)
4	DC36V -	Black (Thick)
5	Alarm_OUT1	Red (Thin)
6	DC36V +	Red (Thick)
7	DC36V +	Red (Thick)
8	Audio_IN(G)	Audio masking
9	Audio_IN	Audio Core
10	Alarm_OUT1	Black (Thin)
11	Alarm_OUT3	Blue
12	Alarm_OUT3	Pink
13	Alarm_OUT4	White
14	Audio_OUT(G)	Audio masking
15	Audio_OUT	Audio Core
16	Video	Video Core
17	Video (G)	Video masking
18	Alarm_OUT2	White and Orange
19	Alarm_OUT4	Green
20	RS485A	Orange (Thick)
21	RS485B	Yellow (Thick)
22	ETHTX+	White and Orange
23	ETHTX-	Orange
24	Alarm_OUT2	White and Yellow
25	ETHRX+	White and Green
26	ETHRX-	Green

1.3.2 Aviation Alarm Cable of Twenty-six Cores

Aviation alarm cable of twenty-six cores is shown as Figure 1-3& Figure 1-4, and the description is shown in Table 1-2.

Figure 1-3 Aviation power supply cable of twenty-six cores



Figure 1-4 Definition of twenty-six cores




Table 1-2 Description of twelve cores

SN	Name	Description
1	Reserved core	Blank
2	Reserved core	Blank


SN	Name	Description
3	Reserved core	Blank
4	Reserved core	Blank
5	Reserved core	Ground
6	Reserved core	Blank
7	Reserved core	Blank
8	Reserved core	Ground
9	Reserved core	Ground
10	Reserved core	Blank
11	Alarm_IN1	White
12	Alarm_IN2	White and Orange
13	Alarm_IN3	Blue
14	Audio_IN(G)	Audio masking
15	Audio_IN	Audio Core
16	Video	Video Core
17	Video (G)	Video masking
18	Audio_OUT	Audio Core
19	Audio_OUT(G)	Audio masking
20	Alarm_IN4	Pink
21	Alarm_IN5	Red (Thin)
22	Alarm_IN6	White and Yellow
23	Alarm_IN7	Blank
24	Alarm_IN8	Yellow (Thick)
25	Alarm_IN9	Orange (Thick)
26	Alarm_G	Black (Thick)

----End

2 Device Dimensions

Figure 2-1 shows the dimensions of the Network PTZ Positioning Camera

Figure 2-1 Dimensions (unit: mm)




3 Device Installation

3.1 Installation Method

Hybrid PTZ Pos. Camera System can be installed on camera base.

Figure 3-1 shows the base dimensions of PTZ camera.

Figure 3-1 Base dimensions of PTZ camera (unit: mm)



3.2 Device Installation

3.2.1 Installation of Basic Requirements

Installation site and environment to meet the technical parameters mentioned in the requirements, the installation staff should have been fully read and read the contents of this manual, with the appropriate system installation qualification and maintenance work qualification certificate.

3.2.2 Basic Installation Tool

Commonly used engineering wiring and equipment installation tools, please install the equipment before the preparation is complete.

Table 3-1 shows the installation tools list.

Table 3-1 Installation tools

Name	Quantity	Remarks
13mm wrench	1	For mounting fixtures and mounting
14mm sleeve	1	brackets
Cross screwdriver(big)	1	For common construction
Cross screwdriver(small)	1	Used to disassemble the DIP cover to adjust the device communication parameters
Inside the hex wrench	1 set	Used for disassembly of pan / tilt pallet and shield connection
Word screwdriver (small)	1	to secure the wiring harness connection terminals
Wire strippers	1	Stripping

3.2.3 Installation Space and Installation Strength

Under normal circumstances, this device needs to be equipped with a protective cover or other overhead items, please confirm the installation location can accommodate this product and the equipment and installation of the structure of the space. To confirm the installation of the wall, the carrying capacity of the bracket can reach 4 times the safety of the entire equipment weight.

3.2.4 Definition of Installation Wiring Harness

The bottom line includes power line, network cable, RS422, geodetic line, video line, and according to the demand, there are various types of outgoing line. The details need to be controlled according to the line signature of each device.

Table 3-2 shows Definition of installation wiring harness.

Table 3-2 Definition of installation wiring harness

COLOR	Function define	Remark
BNC	Video	Optional
Red	DC36V+	
Black	DC36V-	
RJ45	Network cable	
Orange	RS422 TX+	
Yellow	RS422 TX-	
Red	RS422 RX+	
Blue	RS422 RX-	

COLOR	Function define	Remark
Yellow & Green	GND	



In order to prevent lightning strikes, the grounding wire (yellow-green wire) in the cable outlet base must be grounded reliably and the grounding resistance should be $<4\Omega$.

----End

4 Quick Configuration

4.1 Thermal Web

4.1.1 Login and Logout



CAUTION

You must use Internet Explorer 8 or a later version to access the web management system; otherwise, some functions may be unavailable.

Login system

Step 1 Open the Internet Explorer, enter the IP address of IP camera (default value: 192.168.0.121) in the address box, and press Enter.

The login page is displayed, as shown in Figure 4-1.

Figure 4-1 Login page



Step 2 Input the User name and password.

□ NOTE

- The default user name is admin. The default password is admin. Change the password when you log in the system for first time to ensure system security.
- User may change the system display language on the login page.

Step 3 Click Login.

The main page is displayed.

----End

logout

To logout of system, click in the upper right corner of the main page, the login page is display after you log out of the system.

4.1.2 Main Page Layout

On the main page, user may view real-time video, set parameter, Video parameter, Video control, PTZ control, PTZ Configure and log out of the system. Figure 4-2 is shown the main page layout. Table 4-1 lists the elements on the main page layout.



Figure 4-2 Main page layout

Table 4-1 Elements on the main page

No.	Element	Description
1	Real-time video area	Real-time videos are played in this area. User may also set sensor parameters.
2	Playback	User may query the playback videos in this area.
		Only when the SD card or NAS have videos that user can query

No.	Element	Description	
		the playback videos.	
3	Device configuration	User may choose a menu to set device parameters, including the device information, audio and video streams, alarm setting, and privacy mask function.	
4	Change password	User may click to change the password.	
5	Sign Out	User may click to return to the login page.	
6	Stream	Three are three streams. Choose one type from drop-down list.	
7	Pause/Start	Close live video or play live video.	
8	Live/Smooth	Switch image quality.	
9	Audio	Open or close audio.	
10	Interphone	Open or close interphone.	
11	Sensor setting	Click the icon, it will access to sensor setting.	
12	Snapshot	Click the icon, it will snapshot.	
13	Local record	Click the icon, it will record video and save.	
14	Intelligent analysis	Open or close intelligent analysis. Choose stream 2 and enable intelligent analysis > video stream draw line	



- 1. When the device generates an alarm, the alarm icon is displayed. User may click to view the alarm information. When the device accepts an alarm signal, the alarm icon will display within 10s in the web management system.
- 2. When the device encounters an exception, the fault icon is displayed. User may click



----End

4.1.3 Change the Password

Description


User may click to change the password for logging in to the system.

Procedure

Step 1 Click in the upper right corner of the main page.

The **Change Password** dialog box is displayed, as shown in Figure 4-3.

Figure 4-3 Modify Password dialog box



☐ NOTE

The change password page will be displayed if you don't change the default password when you login the system for the first time.

- Step 2 Enter the old password, new password, and confirmation password.
- Step 3 Click **OK**.

If the message "Change own password success" is displayed, the password is successfully changed. If the password fails to be changed, the cause is displayed. (For example, the new password length couldn't be less than eight.)

Step 4 Click **OK**.

The login page is displayed.

----End

4.1.4 Browse Video

User can browse the real-time video in the web management system.

Preparation

To ensure the real-time video can be play properly, you must perform the following operation when you log in to the web for the first time:

Step 1 Open the Internet Explorer. Choose Tools > Internet options > Security > Trusted sites > Sites.

In the display dialog box, click Add, as shown in Figure 4-4.

Close

Connections Programs Advanced Security General Privacy Content Select a zone to view or change security settings Internet Local intranet Trusted sites Restricted You can add and remove websites from this zone. All websites in this zone will use the zone's security settings. This zone contains websites that you trust not to damage your computer or vour files. Add this website to the zone: You have websites in this zone. https://192.168.0.120 Add Security level for this zone Allowed levels for this zone: All https://w.psbc.com - Minimal safeguards and warning prompts are provided Most content is downloaded and run without prompts - All active content can run - Appropriate for sites that you absolutely trust Require server verification (https:) for all sites in this zone Custom level... Default level

Figure 4-4 Adding the a trusted site

Step 2 In the Internet Explorer, choose **Tool** > **Internet Options** > **Security** > **Customer level**, and set Download unsigned ActiveX control and initialize and script ActiveX controls not marked as safe for scripting under ActiveX controls and plug-ins to Enable, as shown in Figure 4-5.

Reset all zones to default level

Figure 4-5 Configuring ActiveX control and plug-ins



Step 3 Download and install the player control as prompted.

M NOTE

The login page is display when the control is loaded.

4.1.5 Install Plugins

You will be prompted with a message "Download and install the new plugin" as shown in Figure 4-6 when you log in to the web management system for the first time.

Figure 4-6 Download the plugin page



Selecting a play mode, please

- Continue to use the old plugin.
- Use the VLC to play
- Download and install the new plugin (Please reopen the browser after installing)

Procedure

- Step 1 Click the message, download and install the plugin follow the prompts.
- Step 2 Reopen the browser after installation.

----End

4.1.6 Set Local Network Parameters

Description

Local network parameters include:


- IP protocol
- IP address
- Subnet mask
- Default gateway
- Dynamic Host Configuration Protocol (DHCP)
- Preferred Domain Name System (DNS) server
- Alternate DNS server
- MTU

Procedure

Step 1 Choose **Configuration** > **Device** > **Local Network**.

The **Local Network** page is displayed, as shown in Figure 4-7.

Figure 4-7 Local Network page



Step 2 Set the parameters according to Table 4-2.

Table 4-2 Local network parameters

Table 1 2 200m network parameters		
Parameter	Description	Setting
IP Protocol	IPv4 is the IP protocol that uses an address length of 32 bits.	[Setting method] Select a value from the drop-down list box. [Default value] IPv4
DHCP	The device automatically obtains the IP address from the DHCP server.	[Setting method] Click the option button. NOTE To query the current IP address of the device, you must query it on the platform based on the device name.
DHCP IP	IP address that the DHCP server assigned to the device.	N/A

Parameter	Description	Setting
IP Address	Device IP address that can be set as required.	[Setting method] Enter a value manually. [Default value] 192.168.0.120
Subnet Mask	Subnet mask of the network adapter.	[Setting method] Enter a value manually. [Default value] 255.255.255.0
Default Gateway	This parameter must be set if the client accesses the device through a gateway.	[Setting method] Enter a value manually. [Default value] 192.168.0.1
Preferred DNS Server	IP address of a DNS server.	[Setting method] Enter a value manually. [Default value] 192.168.0.1
Alternate DNS Server	IP address of a domain server. If the preferred DNS server is faulty, the device uses the alternate DNS server to resolve domain names.	[Setting method] Enter a value manually. [Default value] 192.168.0.2
MTU	Set the maximum value of network transmission data packets.	[Setting method] Enter a value manually. NOTE The MTU value is range from 1280 to 1500, the default value is 1500, Please do not change it arbitrarily.

Step 3 Click **OK**.

- If the message "Apply success" is displayed, click OK. The system saves the settings. The message "Set network pram's success, Please login system again" is displayed. Use the new IP address to log in to the web management system.
- If the message "Invalid IP Address", "Invalid Subnet Mask", "Invalid default gateway", "Invalid primary DNS", or "Invalid space DNS" is displayed, set the parameters correctly.

M NOTE

- If you set only the Subnet Mask, Default Gateway, Preferred DNS Server, and Alternate DNS Server parameters, you do not need to log in to the system again.
- User may click **Reset** to set the parameters again if required.

----End

4.2 Visible-light Web

4.2.1 Login and Logout



CAUTION

You must use Internet Explorer 8 or a later version to access the web management system; otherwise, some functions may be unavailable.

Login system

Step 1 Open Internet Explorer, enter the IP address of the IP camera (default value: 192.168.0.120) in the address box, and press **Enter**.

The login page is displayed, as shown in Figure 4-8.

Figure 4-8 Login page



Step 2 Enter the user name, and password.



- The default user name is admin. The default password is admin.
- Please change the password to ensure system security.
- User may change the system display language on the login page.

Step 3 Click login.

The main page is displayed.

----End

Logout

To log out of the system, click in the upper right corner of the main page. The login page is displayed after you log out of the system.

4.2.2 Main Page Layout

On the main page, user may view real-time videos, receive alarm and fault notifications, set parameters, change the password, and log out of the system. Figure 4-9 shows the main page layout. Table 4-3 describes the elements on the main page.



Figure 4-9 Main page layout

Table 4-3 Elements on the main page

No.	Element	Description
1	Real-time video area	Real-time videos are played in this area. User may also set sensor parameters.
2	Playback	User may query the playback videos in this area.
		Only when the SD card or NAS have videos that user may query the playback videos.

No.	Element	Description	
3	Device configuration	User may choose a menu to set device parameters, including the device information, audio and video streams, alarm setting, and privacy mask function.	
4	Alarm icon	When the device generates an alarm, the alarm icon is displayed. User may click to view the alarm information.	
		NOTE	
		When the device accepts an alarm signal, the alarm icon will display within 10 s in the web management system.	
5	Fault icon	When the device encounters an exception, the fault icon is displayed. User may click to view the fault information.	
6	Change password	User may click to change the password.	
7	Sign Out	User may click to return to the login page.	

----End

4.2.3 Change the Password

Description

User may click


to change the password for logging in to the system.

Procedure

Step 1 Click in the upper right corner of the main page.

The **Change Password** dialog box is displayed, as shown in Figure 4-10.

Figure 4-10 Modify Password dialog box



M NOTE

The change password page will be displayed if you don't change the default password when you login the system for the first time.

- Step 2 Enter the old password, new password, and confirmation password.
- Step 3 Click **OK**.

If the message "Change own password success" is displayed, the password is successfully changed. If the password fails to be changed, the cause is displayed. (For example, the new password length could not be less than eight.)

Step 4 Click **OK**.

The login page is displayed.

----End

4.2.4 Browse Video

User can browse the real-time video in the web management system.

Preparation

To ensure that real-time videos can be played properly, you must perform the following operations when you log in to the web management system for the first time:

Step 1 Open Internet Explorer. Choose **Tools** > **Internet Options** > **Security** > **Trusted** sites > **Sites**.

In the displayed dialog box, click **Add**, as shown in Figure 4-11.

General Security Privacy Content Connections Programs Advanced ect a zone to view or change security settings Trusted sites Internet Local intranet Restricted sites Sites This zone contains websites that you trust not to damage your computer or Trusted sites X your files. You have websites in this zone. You can add and remove websites from this zone. All websites in Security level for this zone this zone will use the zone's security settings. Allowed levels for this zone: All Add this website to the zone - Minimal safeguards and warning prompts are provided - Most content is downloaded and run without prompts https://192.168.0.120 Add - All active content can run Appropriate for sites that you absolutely trust <u>W</u>ebsites: *.hisilicon.com • *.hislicon.com *.huawei.com Custom level... Default level *.huaweidevice.com *.huaweimarine.com Reset all zones to default level Require server verification (https:) for all sites in this zone ⊈lose Cancel

Figure 4-11 Adding a trusted site

Step 2 In Internet Explorer, choose Tools > Internet Options > Security > Customer level, and set Download unsigned ActiveX controls and Initialize and script ActiveX controls not marked as safe for scripting under ActiveX controls and plug-ins to Enable, as shown in Figure 4-12.

? X General Security Privacy Content Connections Programs Advanced Security Settings - Internet Zone × Select a zone to view or change security settings ActiveX controls to run without pro Internet Local intranet Trusted sites Restricted O Disable Enable Allow Scriptlets This zone is for Internet websites, O Disable except those listed in trusted and Enable O Prompt Automatic prompting for ActiveX controls Security level for this zone O Disable Enable Custom Binary and script behaviors Custom settings.

- To change the settings, click Custom level.

- To use the recommended settings, click Default level. O Administrator approved O Disable Enable Display video and animation on a webpage that does not use *Takes effect after you restart Internet Explorer Custom level... Default level Reset custom settings Reset all zones to default level Reset to: Medium-high (default) Reset. OK Cancel Cancel

Figure 4-12 Configuring ActiveX controls and plug-ins

Step 3 Download and install the player control as prompted.

■ NOTE

If the repair tips displayed when installing the control, please ignore the prompt, and continue the installation, the login page is displayed when the control is loaded.

Download the right control in the Internet Explorer

Real-time video page pop-ups the message clicks to play live video with ActiveX control to reduce latency.

Click the message, jump to download ActiveX control interface, once downloading is complete, user may watch more fluent video screen.

Unable to display video picture, and need to download and install the control

Real-time video page pop-up the message click to download the latest version of Flash Play live video and click to play video with ActiveX control to reduce latency.

Click the message **click to play live video with ActiveX control to reduce latency**, jump download Adobe Flash Player Plugin control interface, once downloading is complete, user may watch video screen.

Click the message **click to download the latest version of Flash Play live video**, jump to download ActiveX control interface, once downloading is complete, user may watch more fluent video screen.

In the Google, Firefox, or Safari browsers watch real-time video

Google, Firefox, and Safari browsers only support Adobe Flash Player Plugin to play video. When Adobe Flash Plugin control version is too low, browser will automatically clew you to download the latest control.

----End

4.2.5 Set Local Network Parameters

Description

Local network parameters include:


- IP protocol
- IP address
- Subnet mask
- Default gateway
- Dynamic Host Configuration Protocol (DHCP)
- Preferred Domain Name System (DNS) server
- Alternate DNS server
- MTU

Procedure

Step 1 Choose Configuration > Device > Local Network...

The Local Network page is displayed, as shown in Figure 4-13

Figure 4-13 Local Network page



Step 2 Set the parameters according to Table 4-4.

Table 4-4 Local network parameters

Parameter	Description	Setting
IP Protocol	IPv4 is the IP protocol that uses an address length of 32 bits.	[Setting method] Select a value from the drop-down list box. [Default value] IPv4

Parameter	Description	Setting
Obtain IP address automatically	The device automatically obtains the IP address from the DHCP server.	[Setting method] Click the button on to enable DHCP . NOTE To query the current IP address of the device, you must query it on the platform based on the device name.
DHCP IP	IP address that the DHCP server assigned to the device.	N/A
IP Address	Device IP address that can be set as required.	[Setting method] Enter a value manually. [Default value] 192.168.0.120
Subnet Mask	Subnet mask of the network adapter.	[Setting method] Enter a value manually. [Default value] 255.255.255.0
Default Gateway	This parameter must be set if the client accesses the device through a gateway.	[Setting method] Enter a value manually. [Default value] 192.168.0.1
Preferred DNS Server	IP address of a DNS server.	[Setting method] Enter a value manually. [Default value] 192.168.0.1
Alternate DNS Server	IP address of a domain server. If the preferred DNS server is faulty, the device uses the alternate DNS server to resolve domain names.	[Setting method] Enter a value manually. [Default value] 192.168.0.2

Parameter	Description	Setting
MTU(1280-1500)	Set the maximum value of network transmission data packets.	[Setting method] Enter a value manually.
		NOTE The MTU value is range from 1280 to 1500, the default value is 1500, Please do not change it arbitrarily.

Step 3 Click **Apply**.

- If the message "Apply succeed!" is displayed, click Confirm. The system saves the settings. The message "Set network parameter success, Please login system again" is displayed. Use the new IP address to log in to the web management system.
- If the message "Invalid IP Address", "Invalid Subnet Mask", "Invalid default gateway", "Invalid primary DNS", or "Invalid space DNS" is displayed, set the parameters correctly.

----End

5 Thermal Settings

5.1 Temperature Parameters


Temperature parameters include: temperature unit, ambient type, ambient temperature, cavity temperature, correctional coefficient and area temperature display mode.

Operation Procedure

Step 1 Choose Configuration > Thermal > Temperature Parameters.

The **Temperature Parameters** page is displayed, as shown in Figure 5-1.

Figure 5-1 Temperature Parameters interface



Step 2 Set the parameters according to Table 5-1.

Table 5-1 Temperature parameters

Parameter	Description Description	Setting
Temperature Unit	Celsius and Fahrenheit temperature units are available.	[Setting method] Select a value from the drop-down list box. [Default value] Celsius
Ambient Temperature	The ambient temperature of camera. It is set when ambient is outside.	[Setting method] Enter a value manually.
Cavity Temperature	The cavity temperature of camera.	N/A
Correction Coefficient	Correction coefficient is refer to the deviation of measured object temperature and actual temperature. For example: 1. The measured object temperature is 30, and actual temperature is 37, so the correction coefficient should be 7. 2. The measured object temperature is 37, and actual temperature is 37, and actual temperature is 30, so the correction coefficient should be -7.	[Setting method] Enter a value manually. [Default value] 0.00
Area Temperature Display Mode	The display position of temperature information on the live-video image.	[Setting method] Select a value from the drop-down list box. [Default value] Low left
Font Border	Enable to bold the font	[Setting method] Enable or disable [Default value] Disable
Custom Colors	Enable to custom the color, there are nine colors chosen.	[Setting method] Enable or disable [Default value] Disable

-		I nermai Se
Parameter	Description	Setting
Area Temperature Type	There are three types of area temperature.	[Setting method] Select a value from the drop-down list box. [Default value] Highest Temperature
Measure Mode	There are two types measure modes.	[Setting method] Select a value from the drop-down list box. [Default value] General
Display Alarm Area	N/A	[Setting method] Enable or disable [Default value] Disable
Area Alarm Interval	N/A	[Setting method] Enter a value manually ranges from 1 to 1800. [Default value] 10
Temperature range	It depends the device, different devices have different modes, there are two ranges, such as -20 °C -150°C, -40 °C-150°C.	[Setting method] Select a value from the drop-down list box.

Figure 5-2 Advanced interface



Table 5-2 Advance parameters

Parameter	Description	Setting
Dimming Mode	There are auto and manual modes. It will show on temperature item.	[Setting method] Select a value from the drop-down list box. [Default value] Auto
Greater Prominent	Enable that, the image will show the setting color if the temperature is higher than set value.	[Setting method] Enter a value manually. Choose one color to show.
Section Prominent	Enable that, the image will show the setting color if the temperature is between minimum and maximum temperature.	[Setting method] Enter a value manually. Choose one color to show.
Less Prominent	Enable that, the image will show the setting color if the temperature is lower than set value.	[Setting method] Enter a value manually. Choose one color to show.

Parameter	Description	Setting
Raw Data Upload Interval(F/S)	Interval of Upload the raw data.	[Setting method] Select a value from the drop-down list box. [Default value]
Mix Stream Mode	This function is used for thermal and visible lighting image to mix. There are close, mode 1 and mode 2.	[Default value] Close

Step 3 Click Apply.

The message "Apply success" is displayed, the system saves the settings.

----End


5.2 Temperature Area

Operation Procedure

Step 1 Choose Configuration > Thermal > Temperature Area.

The **Temperature Area** page is displayed, as shown in Figure 5-3

Figure 5-3 Temperature area and alarm configuration



Step 2 Set the parameters according to Table 5-3

Table 5-3 Temperature area and alarm configuration

Parameter	Description	Setting	
Channel	N/A	[Setting method] Select a value from the drop-down list box.	
		[Default value] 1	
Measure Mode	Set at temperature parameter interface.	N/A	
Enable	Tick to enable the areas	N/A	
ID	It ranges from 0 to 19	N/A	
Name	Area name of temperature area.	[Setting method] Enter a value manually.	


Parameter	Description	Setting
Туре	Type of temperature area. ID 0 is default rectangle area, which is full screen.	[Setting method] Select a value from the drop-down list box. [Default value] Rectangle/Point
Alarm Type	Threshold alarm, Section Alarm and Temperature difference alarm are available for alarm type. Section Alarm: if the temperature value is among the set temperature range, it will generate the alarm.	[Setting method] Select a value from the drop-down list box. [Default value] Threshold alarm
Warning Value	Camera will warn when the surveillance object temperature reaches the warning value. At threshold alarm type and difference alarm type can be set.	[Setting method] Enter a value manually. [Default value] 48.00
Alarm Value	Camera will alarm when the surveillance object temperature reaches the alarm value.	[Setting method] Enter a value manually. [Default value] 50.00
Maximum Alarm Value	At section alarm type, the device would not alarm when the temperature is higher than maximum alarm value or less than alarm value.	[Setting method] Enter a value manually. [Default value] 60.00
Emission Rate	The emission rate is the capability of an object to emit or absorb energy. The emission rate should be set only when the target is special material. The emission rate list refers to A Common Emission Rate	[Setting method] Enter a value manually. [Default value] 0.95

Parameter	Description	Setting
Distance(M)	The distance between camera and target.	[Setting method] Enter a value manually. [Default value] 15 NOTE Enter actual distance when the distance between camera and target is less than 15 m. Enter 15 when the distance between camera and target is great than or equal to 15 m.
Alarm	Open or close the alarm output and linkage of area.	[Setting method] Tick the alarm areas

Step 3 **Set temperature area.**

- 1. Tick an area ID.
- 2. Select type from drop-list.
- 3. Press and hold the left mouse button, and drag in the video area to draw a temperature area, as shown in Figure 5-4. Right-click to finish the area selected.

Figure 5-4 Temperature Area Setting Interface



Click Apply, the message "Apply success" is displayed, the temperature area is set successfully.

Delete a temperature area:

- 1. Select an area ID.
- 2. Click the temperature area and right-click.
- 3. Remove the tick of area ID.
- Click Apply, the message "Apply success" is displayed, the temperature area is deleted successfully.

Step 4 Click Apply.

The message "Apply success" is displayed, the system saves the settings.

----End


5.3 Schedule Linkage

Operation Procedure

Step 1 Choose Configuration > Thermal > Schedule Linkage

The **Schedule Linkage** page is displayed, as shown in Figure 5-5.

Figure 5-5 Schedule Linkage



- Step 2 Tick the output channel.
- Step 3 Enable "Alarm Record", "SMTP", "FTP" button.
- Step 4 Set schedule linkage.

Method 1: Click left mouse button to select any time point within 0:00-24:00 from Monday to Sunday as shown in Figure 5-5.

Method 2: Hold down the left mouse button, drag and release mouse to select the alarm time within 0:00-24:00 from Sunday to Saturday.

M NOTE

When you select time by dragging the cursor, the cursor cannot be moved out of the time area. Otherwise, no time can be selected.

Method 3: Click in the alarm time page to select the whole day or whole week.

Deleting alarm time: Click again or inverse selection to delete the selected alarm time.

Step 5 Click Apply.

The message "Apply success" is displayed, the system saves the settings.

----End

5.4 Bad Point Check

Description

The points that can't move when the environment or scenario change is bad point. User may delete the bad point by bad point check function.

Procedure

Step 1 Choose Configuration > Thermal > Bad Point Check

The **Bad Point Check** page is displayed, as shown in Figure 5-6.

Figure 5-6 Bad Point Check



Step 2 Click the white point at image, click **Apply** to recover the bad point, as shown in Figure 5-7

Figure 5-7 Recover bad point

- Step 3 Click **Reset** to return the previous settings.
- Step 4 Click **Apply.** The message "Apply success" is displayed, the system saves the settings. ----End

5.5 Thermal Parameter Configuration

5.5.1 Access the Sensor Setting Interface

Operation procedure:

Step 1 On the web interface or client interface, move the cursor to the real-time video page and right-click on the page. A shortcut menu is displayed, as shown in Figure 5-8, and Table 5-4 describes the sensor setting interface.

Figure 5-8 Sensor Setting interface




Table 5-4 Sensor Setting interface

Parameter	Description
Full Screen	It enlarges and displays the image in full screen.
Sensor Configure	It is used for configuring the parameter set of front-end images.
Zoom In/Out	It zooms in/out images by electronic means. This function may also be used with the mouse wheel.
Open point measurement (Turn on the mouse to measure the temperature)	Click this option to measure the target temperature that the mouse moved.

Step 2 Choose **Sensor Configure** and the **Sensor Setting** dialog box appears.

----End


5.6 Sensor Setting Parameter

5.6.1 Mode

Operation procedure:

Step 1 Click **Mode** tag on sensor setting interface, the Mode page is displayed, as shown in Figure 5-9.

Figure 5-9 Mode page



- Step 2 Choose Debug Model in the lower left corner to activate the sensor setting page.
- Step 3 Set the Mode parameters.
- Step 4 Click **Save** to save the setting.

----End

5.6.2 Image Setting

Figure 5-10 shows the image setting interface.

Figure 5-10 Image setting interface




Table 5-5 describes the image setting parameters.


Table 5-5 Image setting parameter description

Parameter	Description	Setting
Brightness	It indicates the total brightness of an image. As the value increases, the image becomes brighter.	[Setting method]
		Drag the slider.
		[Default value]
		50
Contrast	It indicates the contrast between the bright part and the dark part of an image. As the value increases, the contrast increases.	[Setting method] Drag the slider. [Default value]
		50
Sharpness	It indicates the sharpness of the image plane and the sharpness of the image edge. The shaper the	[Setting method]
	image, the better detail contrast.	Drag the slider.
		[Default value]
		50

5.6.3 Scene

Figure 5-11 shows the scene interface.

Figure 5-11 Scene interface



Provide the selection of image pixel locations.

Normal: the image is not flipped.

Horizontal: the image is flipped left and right.

Vertical: the image is flipped up and down.


Horizontal + Vertical: the image upside-down and reversal.

----End


5.6.4 Set Pseudo color

Figure 5-12 shows the set pseudo color interface.

Figure 5-12 set pseudocolor interface



Polarity/LUT: the temperatures of the temperature fields detected by the thermal imaging camera are separately mapped to values ranging from 0 to 255 by the algorithm. In the black/white display mode, this range is converted to the grayscale tones. For example, 0 indicates completely black, and 255 indicates completely white. The temperature field of the scene is converted to images by using the grayscale ranging from 0 to 255. Different polarity modes can be converted to different display images. The most common setting is white hot (a hotter object is displayed brighter than a colder object) or black hot (a hotter object is displayed darker than a colder object). The difference between two modes lies in that the temperatures corresponding to the darker one and the lighter one are reversed. Other modes include rainbow, ironbow, HSV, autumn, bone and so on.



Temperature strip switch is on, the live video will show it, otherwise is no strip. ----End

5.6.5 FFC Control

Figure 5-13 shows the FFC mode interface.

Figure 5-13 FFC mode interface




Table 5-6 describes the FFC mode parameters.

Table 5-6 FFC control parameter description

Parameter	Description	Setting
FFC Mode	The internal of the thermal imaging camera may comprise the mechanical action correction mechanism that can periodically improve the image quality. This component is called flat field correction (FFC). When controlling the FFC, the FFC shields the sensor array, so that each portion of the sensor can collect uniform temperature fields (flat field). By means of FFC, the camera can update the correction coefficients to output more uniform images. Throughout the FFC process, the video image is frozen for two seconds and a static-frame image is displayed. After the FFC is complete, the image is automatically recovered. Repeated FFC operations can prevent the grainy and image degradation problems. The FFC is especially important when the temperature of the camera changes. For example, after the camera is powered on or the ambient temperature is changed, you should immediately perform the FFC. Auto: In the Automatic FFC mode, the camera performs FFC whenever its temperature changes by a specified amount or at the end of a specified	[How to set] Select from the drop-down list box. [Default value] Auto

Parameter	Description	Setting
	period of time (whichever comes first). When this mode is selected, the FFC interval (minutes) ranges from 5 to 30 minutes. The temperature change of the camera is based on the temperatures collected by the internal temperature probe. The temperature of the camera sharply changes when the camera is powered on. The FFC is relatively frequent, which is normal. Manual: In the manual FFC mode, the camera does not automatically perform the FFC based on the temperature change or the specified period. User may press the Do FFC button to select the manual FFC mode. When you feel that the image is obviously degraded but the automatic FFC is not performed, user may use the manual FFC function to check whether the image quality can be improved.	
FFC Interval (min)	In the automatic FFC mode, the FFC interval ranges from 10 to 255 minutes.	[How to set] Drag the slider. [Default value] 15
Temper Interval	In the automatic FFC mode, the FFC interval ranges from 0.2 to 25.5 centigrade.	[How to set] Drag the slider. [Default value] 5
Shutter Adjust	Click the icon to adjust exposure immediately.	N/A
Background Adjust	Click the icon and cover the camera with something to adjust image. Remove the thing to finish adjustment.	N/A

5.6.6 Noise Reduction

Figure 5-14 shows the Noise reduction interface.

Figure 5-14 Noise reduction interface




Table 5-7 describes noise reduction parameters.


Table 5-7 DNR parameter description

Parameter	Description	Setting
2 DNR	Decrease the image noise.	[How to set] Select from the drop-down list box. Drag the slider to adjust max strength. [Default value] Auto
3 DNR	Decrease the image noise.	[How to set] Select from the drop-down list box. Drag the slider to adjust max strength. [Default value] Auto

5.6.7 Enhance Image

Figure 5-15 shows the screen adjustment interface. shows the screen adjustment parameter.

Figure 5-15 Enhance image interface



Tick the defog and drag the slider to adjust the value.

Click **Save** to save the parameters.

----End


6 Visible Sensor Configuration

6.1 Accessing the Sensor Interface

Procedure

Step 1 On the web interface, move the cursor to the real-time video page and right-click on the page. A shortcut menu is displayed, as shown in Figure 6-1

Figure 6-1 Sensor setting interface



Step 2 Choose **Sensor Configure** and the **Sensor Setting** dialog box appears.




• All sensor configure can be modified at debug mode. Click left corner of Sensor Setting, and choose **Debug Mode.**

6.2 Mode

Step 3 Click Standard in the lower left corner of Sensor Setting, and choose **Debug**Mode. As shown in Figure 6-2.

Figure 6-2 Mode



- Step 4 Choose the switch mode from the drop-down list.
- Step 5 Time mode: Set the Start Time, set the End Time. DN linkage Mode, the day mode is correspond to scheme 1, the night mode is correspond to scheme 2.
- Step 6 Click **Save**, the message "**Save succeed**" is displayed, the system saves the settings.

Step 7

6.3 Image Adjust

Figure 6-3 shows the Image Adjust tab page.

Figure 6-3 Image




Table 6-1 describes the parameters on the Image Adjust tab page.

Table 6-1 Parameters of Image

Parameter	Description	Configuration Method
Brightness	It indicates the total brightness of an image. As the value increases, the image becomes brighter.	[Setting method] Drag the slider. [Default value] 50
Sharpness	It indicates the border sharpness of an image. As the value increases, the borders become clearer, and the number of noise points increases.	[Setting method] Drag the slider. [Default value] 50
Saturation	It indicates the color saturation of an image. As the value increases, the image becomes more colorful.	[Setting method] Drag the slider. [Default value] 50

Contrast It indicates the measurement of different brightness levels between the brightest white and darkest black in an image. The larger the difference range is, the greater the contrast; the smaller the difference range is, the smaller the contrast.	
---	--

6.4 Scene

Figure 6-4 shows the scene tab page.

Figure 6-4 Scene




Table 6-2 describes the parameters on the scene tab page.

Table 6-2 Parameters of scene

Parameter	Description	Configuration Method
Scene	Indoor or outdoor.	[Setting method] Select a value from the drop-down list. [Default value] Outdoor

Mirror	It is used to select the pixel location of an image. Normal: The image does not flip. Horizontal: The image flips to the left and right.	[Setting method] Select a value from the drop-down list. [Default value] Normal
	Vertical: The image flips up and down. Horizontal+ Vertical: The image rotates at 180 degrees.	

6.5 Exposure

Figure 6-5 shows the Exposure tab page.

Figure 6-5 Exposure




Table 6-3 describes the parameters on the Exposure setting tab page.

Table 6-3 Parameters of exposure setting

Parameter	Description	Configuration
- urummeter	2 escription	Method
Exposure Mode	The exposure modes include: • Auto: The system performs auto exposure based on the monitoring environment. Manual: User may set Shutter Setting to fixed values manually. Shutter Priority: User may set Iris Setting to fixed values. The shutter and gain are automatically adjusted by the system.	[Setting method] Select a value from the dropdown list. [Default value] Auto
Meter area	Choose the area to meter, there are whole, center spot, and center area.	[Setting method] Select a value from the dropdown list. [Default value] Whole
Max Shutter	It is valid in Iris Priority mode. User may select a maximum shutter speed. As the value increases, the image becomes brighter.	[Setting method] Select a value from the dropdown list. [Default value] 1/25
Max gain	It indicates the maximum gain. The device automatically adjusts the gain based on the external light, and the gain is less than or equal to the value of this parameter.	[Setting method] Drag the slider. [Default value] 50

6.6 WB

Figure 6-6 shows the WB tab page.

Figure 6-6 WB




Table 6-4 describes the parameters on the WB tab page.

Table 6-4 Parameters of WB

Parameter	Description	Configuration Method
Mode	It is used to display the real color of a monitoring scenario when the color temperature changes. Auto: camera adjusts automatically. Tungsten: at tungsten lamp environment. Fluorescent: fluorescent environment. Daylight: at daylight environment. Shadow: at low light environment. Manual: adjust red and blue gain manually.	[Setting method] Select a value from the drop-down list. [Default value] Auto

6.7 DayNight

Figure 6-7 shows the day-night tab page.

Figure 6-7 Day-night




Table 6-5 describes the parameters on the day night tab page.

Table 6-5 Parameters of day night

Parameter	Description	Configuration Method
DayNight Mode	It can be set to Auto, Day Mode, Night Mode and Timing. Auto mode The image color is adjusted based on the day/night mode. In auto mode, the image switches between the colored state and the black and white state based on the brightness. In day mode, the image is colored. In night mode, the image is black and white. Day mode The image is colored, and the filter is in the day state, preventing infrared light from entering the sensor. Night mode The image is black and white, and the filter is in the night state, allowing all types of light to enter the sensor. Timing Select time from the drop-down list by the "Day To Night Time" and "Night To Day Time".	[Setting method] Select a value from the drop- down list. [Default value] Day Mode
Trans (D to N)	Day transit to night.	[Setting method] Drag the slider. [Default value] 50
Trans (N to D)	Night transform to day.	[Setting method] Drag the slider. [Default value] 50
Delay	N/A	[Setting method] Drag the slider. [Default value] 5

6.8 Noise Reduction

Figure 6-8 shows the noise reduction tab page.

Figure 6-8 Noise Reduction




Table 6-6 describes the parameters on the noise reduction tab page.

Table 6-6 Parameters of noise reduction

Parameter	Description	Configuration Method
2D NR	Auto /manual, default value is auto. By comparing and screening the images of the two frames before and after, the noise point position is found out and gain control is carried out on them.	[Setting method] Drag the slider strength. [Default value] Auto / 50
3D NR	Auto /manual, default value is auto. The 3D digital noise reduction function can reduce the noise interference of the weak signal image.	[Setting method] Drag the slider of strength. [Default value] Auto / 50

----End

6.9 Enhance Image

Figure 6-9 shows the enhance image Setting tab page.

Figure 6-9 Enhance image



Table 6-7 describes the parameters on the enhance image setting tab page.

Table 6-7 Parameters of enhance image

Parameter	Description	Configuration Method
WDR	It is intended to provide clear image performance in strong backlight areas such as exterior light coming through a window or glass door. High contract light conditions are no longer a problem when you need to capture detailed images.	[Setting method] Drag the slider. [Default value] 50
HLC	It indicates reverse bright points in the picture to black. As an effective approach to recognize vehicle plate number at night, HLC function can detect any spotlight diffused by object-vehicle and compensate it for obtaining clearer image.	[Setting method] Drag the slider. [Default value] 50

BLC	It indicates Back Light Compensation (BLC) automatically brings more detail to darker areas of an image when bright light shining from behind obscures it and provides perfect exposure for an object in front of very strong back light. The electronic shutter of the camera basically adjusts its exposure to try to allow for more light to be allowed in the darker areas. NOTE This parameter applies only to visible light.	[Setting method] Drag the slider. [Default value] 50
Anti-shake	When the camera shakes out, it is processed by algorithm compensation	[Default value] Disable
Defog	It indicates the camera defog automatically.	[Setting method] Drag the slider. [Default value] 50

6.10 Zoom Focus

Figure 6-10 shows the enhance image Setting tab page.

Figure 6-10 Zoom focus




Table 6-8 describes the parameters on the enhance image setting tab page.

Table 6-8 Parameters of zoom focus

Parameter	Description	Configuration Method
D/N Auto Focus	Enable the function, if the day or night is transform, it will focus automatically.	[Setting method] Tick
	:zoom out :zoom in :near focus :far focus	[Setting method] Click
Auto focus once	N/A	[Setting method] Click
Lens initialization	N/A	[Setting method] Click

7 PTZ Function Application

7.1 PTZ Control function

Operation Description

PTZ Control function is only available to a camera with an external PTZ and High Speed Dome with PTZ function.

PTZ Control

When browsing real-time videos shot by a dome camera or a camera connected to an external PTZ, user may control the PTZ to view Video shot in different directions.

In the PTZ control area, user may click the eights arrow keys to move the PTZ in eight directions, as shown in Figure 7-1.





Figure 7-1 PTZ Control zone

It may also control the iris, zoom and focus of the camera lens through other buttons in the PTZ control zone. Functions of each button are as shown in Table 7-1.

Table 7-1 Descriptions of PTZ buttons

Button	Description
Auto Zoom	Click or to adjust the surveillance range of the front-end lens.




7.2 PTZ configuration

7.2.1 PTZ Setting

Click [172], the PTZ configuration interface displayed, as shown in Figure 7-2.

Figure 7-2 PTZ Configuration



Through this interface, user may perform the following operations:

Add, Delete and Apply a Preset, Track, Scan and Tour.

Set and enable Idle.

Set the direction to due north.

Any direction can be set as the reference due north.

Configure Timer.

----End


7.2.2 Configure and Apply Preset

User may configure preset positions and quickly rotate the camera to preset position by applying the preset.

Operation procedure

Step 1 Click **Preset** tab page in the PTZ configuration interface, the add preset page is displayed, as shown in Figure 7-3.

Figure 7-3 Add Preset



- Step 2 Select a preset ID (such as 1) from the Preset drop-down list box and enter the name of preset.
- Step 3 Use eight arrow keys in the **PTZ control** area to configure a position, then click to complete adding a preset.
- Step 4 Select a Preset name from the Preset drop-down list box and click to apply the preset.

M NOTE

Up to 255 Presets can be configured

----End


7.2.3 Configure and Apply Tracks

User may record a track to allow the camera to repeatedly rotate based on the preset track.

Operation procedure

Step 1 Click **Track** tab page in the PTZ configuration interface, the add track page is displayed as shown in Figure 7-4.

Figure 7-4 Add Track



- Step 2 Select a track ID (such as 1) from the track drop-down list box and enter the name of track.
- Step 3 Click then use eight arrow keys in the **PTZ control** area to configure a track, then click to complete adding a track.
- Step 4 Select a Track name from the Track t drop-down list box and click to apply the track.

M NOTE

Up to 6 Tracks can be configured.

----End


7.2.4 Configure and Apply Scan

User may configure a Scan to rotate the camera between two positions by applying the Scan.

Operation procedure

Step 1 Click **Scan** tab page in the PTZ configuration interface, the add Scan page is displayed, as shown in Figure 7-5.

Figure 7-5 Add Scan



- Step 2 Select Scan ID (such as 1) from the track drop-down list box and enter the name of scan.
- Step 3 Click , then use eight arrow keys in the **PTZ control** area to configure two positions, then click to complete adding a scan.
- Step 4 Select a Scan name from the Scan t drop-down list box and click to apply the scan.


7.2.5 Configure and Apply Tour

User may configure a tour to rotate the camera between presets set by PTZ.

Operation procedure

Step 1 Click **Tour** tab page in the PTZ configuration interface, the add tour page is displayed, as shown in Figure 7-6.

Figure 7-6 Add Tour



- Step 2 Select Tour ID (such as 2) from the drop-down list box, enter the tour name.
- Step 3 Select first required position preset from the **preset** drop-down list box.
- Step 4 Input the values from **Wait Time** area box to set the time to stay in this position preset.(0 sec~ 255 sec).
- Step 5 Click button to begin setting tour.
- Step 6 Click in the add tour page; select next position preset form the preset dropdown list box, and then input the values from Wait Time area box to set the time to stay in next position preset.(0 sec~ 255 sec).
- Step 7 Repeat former step until all required position presets are completed adding.
- Step 8 Click to complete adding a tour (You also can click Cancel button to quit current setting).
- Step 9 Select a tour name and preset from the tour and preset drop-down list box, and then click to apply the tour.


7.2.6 Configure and Applye Idle

User may configure an idle to 'apply preset. Scan, Track, or Tour regularly.

Operation procedure

Step 1 Click **Idle** tab page in the PTZ configuration interface, the idle page is displayed, as shown in Figure 7-7.

Figure 7-7 Idle



- Step 2 Select a monitor type from the **Type** drop-down list box. Monitor type can choose preset, Scan, track, tour and Cir Scan.
- Step 3 Select a name form the **Name** drop-down list box.
- Step 4 Input a value from the **Wait Time** area box.
- Step 5 Click to completed adding an idle.
- Step 6 Click to enable idle function.

7.2.7 Configure North

Operation procedure

Step 1 Click **North** tab page in the PTZ configuration interface, the north page is displayed as shown in Figure 7-8.

Figure 7-8 North



Click to set the current position of true north. Step 2

----End

7.2.8 Configure Timer

Operation procedure


Click Timer tab page in the PTZ configuration interface, the set timer page is Step 1 displayed, as shown in Figure 7-9.

Figure 7-9 Set Timer



Click , the Timer page is displayed, as shown in Figure 7-10. Step 2

Figure 7-10 Timer



- Step 3 Check Enable box.
- Step 4 Select the timer mode.

Issue V1.1 (12-3-2025 69

- Step 5 Select the required begin time at the **Begin Time** drop-down list box, and then select the required end time at the **End Time** drop-down list box.
- Step 6 Select the required monitor type at the PTZ type drop-down list box, user may select preset, Scan, Track, Tour in the box, and then select a specific from the **Name** drop-down list box.(for example preset, 1).
- Step 7 Repeat Step 5 and Step 6 to add more required time.
- Step 8 Click to complete timer setting.

7.2.9 Configure Extension

User may use extension function including lamp and brush.

Operation procedure

Step 1 Click **Extension** tab page in the PTZ configuration interface, the extension page is displayed, as shown in Figure 7-11.

Figure 7-11 Extension



Step 2 Click to enable the lamp.

Light On/Off is used to control the infrared camera shields on and off. It's available only to specific camera shields.

Click to enable the brush.

Brush is used to clean the lens. It's available only to a camera with a brush or a camera shield.

----End

A Troubleshooting

Common Trouble	Possible Cause	Solution
Unable to access the web	Network is not connected.	Connect the network cable of the camera to the PC to check whether the network cable is in good contact. Run the ping command to check the network
		connection and whether the device works normally.
	IP address is occupied.	Directly connect the camera to the PC, and reset the IP address of the camera.
	The IP addresses of the PC and the device are in different networks.	Check the IP address, subnet mask and gateway setting of the camera.
PTZ or high speed dome is out of control.	The protocol, bit- rate, or address setting of the PTZ is incorrect.	Modify the address of the PTZ on the web.
	The signal cable is unconnected or not connected correctly.	Check the signal strength, and reconnect the signal cable.
The measured temperature is not accurate.	The device is just powered on, and the temperature of the cavity is unstable.	The temperature of the cavity is stable within 15 to 30 min after the device is powered on.
	The FFC mode is incorrect.	The FFC mode is auto by default. If the mode is set to manual, it will be no block calibration, which may lead to fuzzy pictures and inaccurate temperature.
	The target configuration is incorrect.	Check whether the emission rate and distance of the target are configured correctly.

		1 12 1 unction Applica	
Common Trouble	Possible Cause	Solution	
An error occurs in accessing the web of the device after the upgrade.	The data in the cache of browser is not updated in time.	Delete the cache of the Internet Explorer. The steps are as follows (taking IE9 as an example):	
		1. Open the Internet Explorer.	
		2. Select Tools > Internet Options .	
		3. On the General tab, select Delete under	
		Browsing history.	
		The Delete Browsing History dialog box appears.	
		4. Select all check boxes.	
		5. Click Delete .	
		Relogin the web page of the camera.	
Upgrade failed.	No network cable is connected.	Ensure the upgrade network is connected.	
	The network setting is incorrect.	Check whether the network setting is correct.	
	The upgrade package is incorrect.	Perform the correct upgrade package again.	
No self-test no image	There is a broken line in the circuit	Find breakpoints, rewiring.	
output	Low supply voltage	Replace the power adapter to increase the output voltage.	
Self-test exception	Low supply voltage	Replace the power adapter to increase the output voltage.	
Equipment control is	Poor video circuit contact	Troubleshooting, rewiring	
normal, image instability (Analog	Access device exception	Replacement access device	
video)			
Equipment control is normal, image instability (Web video)	Network line bad contact	Dismantling bad point, re-wiring.	
	Access to computer performance is insufficient, take up CPU usage	Lower stream and resolution	

P1Z Function A				
Common Trouble	Possible Cause	Solution		
	Lack of network bandwidth	Replacement of industrial Gigabit switches		
	Access decoder performance decoder	Replacement of high-performance		
Self-test normal, can not control	Wrong wiring	Rewiring		
	Set the baud rate, protocol, address and device mismatch	Screen configuration according to device parameters		
Repeated restart	Insufficient supply voltage or voltage instability	To ensure that the input device voltage stability		
Can not control the lens to perform zoom and Focus action	Wiring error	Re-connect the lens control line		
	Circuit board lens control problems	Replacement circuit board (please contact after- sales rework processing, do not replace parts or repair)		
Can not recall the set lens preset point	DIP switch relative to the set lens preset dialing is not set to ON	DIP switch control lens preset dialing dial into ON		
The image is lost when the control device rotates	Rotation process at the same location lost image	Conductive slip ring there is a bad contact, replace the parts (please contact after-sales rework, do not replace parts or repair)		

Brick (Red, rough)	21/70	0.93
Brick (Unglazed, rough)	1000/1832	0.8
Carbon (T - carbon 0.9% ash)	127/260	0.81
Concrete	-	0.94
Glass (Glossy)	22/72	0.94
Granite (Surfaced)	21/70	0.85
Ice	0/32	0.97
Marble (I Polished, grey)	22/72	0.93
Asbestos board	23/74	0.96
	38/100	0.93
Asbestos paper	371/700	0.95
Asphalt (Paving the road)	4/39	0.97
Paper (Black tar)	-	0.93
Paper (White)	-	0.95
Plastic (White)	-	0.91

101-500-0242-02